

## **Error Codes List**

Models: AOU-226VRDC3B AOU-281VRDC3B AOU-336VRDC3B (Refrigerant R410A)

Error Code	Content	Error Code	Content		
E0	Malfunction of ODU (uniform)	E1	High-pressure protection		
E2	Discharge low-temperature protection	E3	Low-pressure protection		
E4	High discharge temperature protection of compressor	E5	High discharge temperature protection of compressor 1		
F0	Main board of ODU is poor	F1	Malfunction of high-pressure sensor		
F3	Malfunction of low-pressure sensor	F5	Malfunction of discharge temperature sensor of compressor 1		
J1	Over-current protection of compressor 1	b1	Malfunction of outdoor ambient temperature sensor		
b2	Malfunction of defrosting temperature sensor 1	b4	Malfunction of liquid temperature sensor of sub-cooler		
b5	Malfunction of gas temperature sensor of sub-cooler	P0	malfunction of driving board of compressor (uniform)		
P1	Driving board of compressor operates abnormally (uniform)	P2	Voltage protection of driving board power of compressor (uniform)		
P3	Reset protection of driving module of compressor	P4	Drive PFC protection of compressor		
P5	Over-current protection of inverter compressor	H0	Malfunction of driving board of fan (uniform)		
H1	Driving board of fan operates abnormally (uniform)	H2	Voltage protection of driving board power of fan (uniform)		
H3	Reset protection of driving module of fan	H4	Drive PFC protection of fan		
H5	Over-current protection of inverter fan				



WWW.ALPICAIR.COM