



⚠ WARNING

Please don't touch any electronic component or terminal when the machine is running, stopping or has been powered off for less than 30 minutes to prevent the risk of electric shock!

Model:
AM30-71HRDC1A
Electrical Drawing

